

# How to Build a Sand Box (12 x 16 ft )

## Materials

- (7) 8 ft x 6 inch x 2 inch wood planks
- (6) 8 ft x 4 ft x 1/4 inch plywood sheets
- (1) 16 ft x 20 ft waterproof heavy gauge plastic sheet
- (8) small pieces of scrap 1/4 in plywood for splints
- 1 box 4 inch wood screws
- 1 box of 2 inch wood screws

## Procedure

- A. Place plastic sheet on floor.
- B. Arrange plywood sheets, centre them on plastic sheet.
- C. Cut one of the planks in half and splint all the planks together, creating the correct lengths for the walls of the box. (2) 16 ft walls and (2) 12 ft walls.
- D. Lift the box into position on top of the plywood sheets.
- E. Excess plastic sheet visible around box is then rolled up to cover the outside of the box and stapled into place, creating a shallow, waterproof basin to place the sand in.
- F. It is not necessary to screw or fasten the box to the plywood sheets.

